

When you see streaking in your work, it is time to refill your marker.

Drip and dab method

1. Hold the marker in one hand, at a slightly tilted angle, with the flat side of the Broad or Medium Broad Nib up.
2. With your other hand, gently dab 15-20 drops onto the nib surface, allowing each drop to be absorbed before adding the next.

Match the color number of your marker with the color number on the Various Ink Cap

Refilling Wide Markers

Hold the marker at a 45° angle, then drip and dab Various Ink into the provided notch. Holds up to 5cc's

Broad Nib or Medium Broad Nib

Notes: Try not to overfill. If overfilling occurs, use a tissue to absorb the extra ink. Maximum fill: Sketch 3cc, COPIC 4cc. Use rubbing alcohol to clean any ink spills or to wipe your marker clean. You can rinse dirty caps in alcohol and wipe the insides clean with a cotton swab.

COPIC: Using the Booster

1. Screw the booster needle onto your various ink bottle. Carefully remove the protective cap.
2. For COPIC markers carefully insert the booster along the side of the nib.
3. Add 2-3cc's ink (depending on how empty your marker is). The back of the Various Ink bottle has measurements on it. Immediately replace the marker cap when done.

Sketch: Using the Booster

1. Screw the booster needle onto your various ink bottle. Carefully remove the protective cap.
2. For Sketch markers, remove the Med. Broad Nib from your marker.
3. Add 2-3cc's ink (depending on how empty your marker is). The back of the Various Ink bottle has measurements on it. Immediately replace the nib and marker cap when done.

COPIC Booster Warnings!



- Booster is sharp.
- Always recap after use.
- Not intended for children.
- Clean Booster with Rubbing alcohol after each use.

